



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAYS 1L/R: Intercept and proceed via SFO R-350. Cross SFO R-350/4 DME fix at or above 1600'. Turn left heading 200° to intercept and proceed via PYE R-135. Cross PORTE DME fix at or above 9000' and PESCA DME fix at or above 13,000'. Then turn left heading 090° to intercept and proceed via the OSI R-116 to WAGES INT. Cross WAGES INT at or above FL 200 or assigned lower altitude or flight level. Thence via (transition) or (assigned route). Expect clearance to filed altitude 10 minutes after departure.

TAKE-OFF RUNWAYS 10L/R and 19L/R: Turn left and climb via the SFO R-090 to intercept the OAK R-135 at or above 5000'. Proceed via the OAK R-135 to WAGES INT. Cross the OAK R-135/25 DME fix at or above 9000'. Cross WAGES INT at or above FL 200 or assigned lower altitude or flight level. Thence via (transition) or (assigned route). Expect clearance to filed altitude 10 minutes after departure.

TAKE-OFF RUNWAYS 28L/R: Intercept and proceed via the SFO R-281, cross SFO R-281/6 DME fix at or above 2500', then turn left heading 180° to intercept and proceed via the PYE R-135 to cross PORTE DME fix at or above 9000' and PESCA DME fix at or above 13,000'. Then turn left heading 090° to intercept and proceed via the OSI R-116 to WAGES INT. Cross WAGES INT at or above FL 200 or assigned lower altitude or flight level. Thence via (transition) or (assigned route). Expect clearance to filed altitude 10 minutes after departure. When SFO VOR/DME is inoperative, Rwy 28 departures expect radar vector to PYE R-135 then resume SID.

AVENAL TRANSITION (PORTE3.AVE): From over WAGES INT via OSI R-116 and AVE R-298 to AVE VORTAC.

CLOVIS TRANSITION (PORTE3.CZQ): From over WAGES INT via CZQ R-260 to CZQ VORTAC.

FELLOWS TRANSITION (PORTE3.FLW): From over WAGES INT via FLW R-306 to FLW VORTAC.

PANOCHÉ TRANSITION (PORTE3.PXN): From over WAGES INT via PXN R-274 to PXN VORTAC.

SW-2, 03 JUL 2008 to 31 JUL 2008

SW-2, 03 JUL 2008 to 31 JUL 2008